



BMW Bluetooth External Amplifier Installation Notes

Installation Procedure.

1. Unwrap the ULF Control Module Harness
2. After unwrapping, you will see a Red, Black and White wires.
3. Connect the Red Wire to the Amplifiers Power Positive Connection.
4. Connect the Black Wire to the Amplifiers Power Negative Connection.
5. Locate the Orange wire and Cut the Wire in half in the center of the harness.
PLEASE NOTE: There may be an Orange/Black wire, DO NOT CUT THIS.
6. Locate the White/Orange wire. (White wire with Orange Stripe.) and cut this wire in half in the center of the harness
7. Connect the Orange and Orange/White wire from the DB25 (Side that connects to the vehicle.) to the Amplifiers Speaker Connection. Polarity does not matter.
8. Connect the Orange and Orange White wire from the ULF Module side to the Amplifiers Input Connection. Polarity does not matter.
9. After connecting verify connections and ensure that the sound is good. Use the volume control to put the volume to the correct level.
10. Wrap harness back up. Ensure there are no exposed wires.

